



All-weather mat for tunnel



565 061 580

ŠKODA KODIAQ

Material: TPE

Practical accessory | Protection | Tests

The all-weather mat for the centre tunnel from the ŠKODA Original Accessories range is a practical **addition to the rear all-weather mats**. The mat **protects** the surface of the centre tunnel from dirt from rear passengers' footwear. Before you place any other mats in the vehicle, put the all-weather mat for the centre tunnel in place first. Then you can lay down the other mats on the vehicle floor. The mat for the centre tunnel fits perfectly and retains its shape. Made from **high-quality TPE material**, it is perfect for the job. Rigorous **performance tests** carried out by ŠKODA have shown the mat to have excellent resistance to wear and tear and deformation. When it is not in use, the product should be stored away from direct sunlight. It should not be packed away in a confined space.

Associated products:

All-weather interior mats, front / 566 061 502 / 567 061 502

All-weather interior mats, rear / 565 061 512

Boot dish – plastic / 565 061 162

Color: Black

Installation time: 20 TU

Set contents:

All-weather mat for the tunnel, fitting instructions.

Installation position:

The mat must be placed onto the vehicle's centre tunnel – no fastenings are needed to keep it in place. The bottom edges of the mat must be pushed underneath the TPE mats in the rear.

Maintenance:

Conventional cleaning agents. Do not use abrasive cleaning agents or solvents.

Guarantee: 24 months.

Does not apply to signs of normal wear and tear.

Weight: 0.62 kg

Comfort & utility